



1. Insert threaded glide into leg as shown.
2. Slide extension pieces outward so they are flush with the inside of the wood rail and leg is centered in bed.
3. Lock support leg into position by hand-tightening the L bolt.
4. Position center supports 15", 40" and 65" from the headboard as shown.
5. Screw center supports to center support bearer rail (wood lip on inside of wood rails) as shown.
6. Adjust glides to float just off the floor, approximately 1/16".