




How do I link my control to the Comfort Base?

Connecting 1 Remote to 1 Base



1. Press and hold the Link button (the black round button on the control box located on the bottom of the base) until the LED light on the control box turns on and then off. Release the button and the LED light will blink.



2. Simultaneously press and hold the Head Up and Foot Up button (the left button and middle button located on the top row of the remote) until the remote's backlight starts blinking.

Release the two buttons and the backlight and the LED light on the control box will blink until linked, then they will turn off.

3. Test the bed to make sure it is working, and repeat steps if it is not.



ComfortBase[®]

If you have repeated these steps a couple of times and you find you still cannot link the remote to the base, please call 855-581-3095 for further assistance.